

DGT 3000



NOTE: This clock uses menu options that are visibly selected. Pay attention to the blinking text on the display for current selection.

NOTE: The GO/NEXT button (far right) and the PLAY/PAUSE button (center) have similar look.

1. **Start/Stop:** ON/OFF button is at the bottom
2. **Select option 30:** With clock on, the option selected will blink at the bottom of the display. Use +/- buttons to navigate to 30. Press GO/NEXT button on far right to select.
3. Enter edit mode: DGT clocks are in edit mode by default
4. **Set time:**
 - a. **Select Delay option:** The delay option will blink on top right. Use +/- buttons to navigate to US-DLY (US Delay).
 - b. **Set time:** Current digit is blinking on display.

Use +/- to change. Press GO/NEXT (far right) to move forward to next digit. Set time to 1:30:00 for both players (or another suitable time).

0.05 BNS 0.05

Press GO/NEXT to move forward to next setting

- c. **Set Delay:** Delay is set for each player separately. Display should read as shown for 5 second delay
 - d. Press GO/NEXT repeatedly to accept all other blinking options
5. **Exit Edit mode:** This is automatic after all settings are complete
 6. **Save settings:** The clock remembers previous settings.
If you want to change the times, just change the times. The clock will be in edit mode by default
 7. Press the PLAY/PAUSE button in the center to start play

Future Use:

1. Turn the clock on. If necessary, press either + or - until (option) "30" is shown on the bottom part of the display.
2. Press the center PLAY/PAUSE button once.

Additional time:

1. Press the PLAY/PAUSE button briefly to pause play
2. Press the PLAY/PAUSE button for three seconds to modify time and move counter (if used)
 - a. Change the +/- buttons to change the blinking digit
 - b. Use the GO/NEXT button to advance to the next digit
 - c. After time, move counter may also be similarly changed
3. Press the PLAY/PAUSE button to restart timer