

ZMF II / ZMF Pro



1. Start/Stop. ON/OFF slider is at the top of the clock
2. Enter edit mode. Hold center button down for 5 seconds till display flashes

In **edit** mode

- a) The digit to be modified will blink on the display.
- b) The Right play button will increase the blinking value.
The Left play button will decrease the blinking value.
- c) Use the center button to set and advance
- d) Press the check to move to the next setting

3. Set time
 - a. Press the right button till you see INC 00 (increment). Both will blink
 - b. Press center button to SELECT and make **just** 00 blink
 - c. Press right button to set INC to 5. Then press select to fix.
 - d. Press left button till you get to HH:MM HH:MM.
 - e. Press center button to edit
 - f. Change each value by using the right/left button to increase/decrease to 1:30 (or alternate time control) and press select to fix and move forward
 - g. Press select when all times are set
4. Exit edit mode: Edit mode will be automatically exited when the time is set.
5. Play by pressing one of the player buttons

Future Use:

1. Settings are automatically saved unless changed.
2. Just press the center button to start.

Additional time:

1. [TBD]